





SOFT, DRY CLOTH




CHEMICAL



HEAT



KEEP DRY



HANDLE WITH CARE




DO NOT USE KNIFE


# ASSEMBLY INSTRUCTION

MODEL : EC 60122-S5V - EMMA MEUBLE TV / TV KAST / TV CABINET


## Step 14




## Step 15




## Step 16



## Step 17



## Step 18



## Completed

